MACHINE CUTTING ACCESSORIES

TH-98 TWIN TIP ADAPTER

Adjustable twin adapter for two cuts simultaneously using one torch. Adjust from 30 mm to 305 mm wide (special widths available upon request), 0-ring sealed, large capacity (up to 200 mm to each tip).



BV-98-2 BEVELLING HEAD

Use with natural gas or propane only. Increases speed and quality of bevel cuts. 6290 cutting tips can be used. Use specially designed 1390-3H replacement heating tip for optimum results.



S-98-C ADJUSTABLE TIP ADAPTER

Allows adjustment of tip to any angle without moving the sealed torch 0-ring, large capacity (up to 200 mm), calibrated to 90° .



96-DC OXYGEN SAVER

Dual control oxygen saver for three hose torches. Connects to oxygen line. Moving the lever adjusts the flame from an extreme flame for piercing and quick starts to a soft small flame for economy and quality. Advantages are reduced oxygen and gas consumption, very high cut quality, square edges, slag-free cuts with fast starts.

Not recommended for acetylene.



C-98-V2 FLASH CHECK VALVE

Check valve for cutting oxygen inlet on three-hose torches. Stops reverse flow of gases.

Recommended when cutting oxygen valve is remote from torches

Cutting capacity up to 200 mm.



88-6 CHECK VALVES

Reverse flow check valves for preheat only. Prevents dangerous reverse flow mixing of gas in hose and regulators (see page 113 for complete check valve information).





